

516-78
JES
8/20/73

DUMP

A routine has been written to enable a 516 user to print the contents of a file in octal. The program may be called from either the FSNAP or system executives.

SYS? DUMP,FILE

FSNAP- DUMP,FILE

FILE is any file on the 516.

The file will be printed out 8 words to a line. Each line will be numbered in octal, starting at 0.